



PHANTOM





PHANTOM
Covered saucepan 18cm - 2L

15.900

BH3950574



PHANTOM
Covered casserole 20cm - 2,6L

18.900

BH3950575



PHANTOM
Covered stockpot 24cm - 4,3L

22.900

BH3950576



PHANTOM
Covered stockpot 24cm - 5,5 L

24.900

BH3950577



PHANTOM
Covered stockpot 24cm - 7,2 L

28.900

BH 3950578



PHANTOM
Cov. 2H sauté pan 28 cm - 4,70 L

23.900

BH3950579

BergHOFF[®]





PHANTOM
Frying pan 28cm

13.900

BH3950571



PHANTOM
Frying pan 24cm

11.900

BH3950570



PHANTOM
Frying pan 20cm

9.900

BH3950569



PHANTOM
Grill pan 26cm

14.900

BH3950573



PHANTOM
Pancake pan 25cm

10.900

BH3950582